## Hole Layout for NBF32026

WiredWatts.com



WiredWatts.com

Cut

Cut

								U			
Cut		Cut	Cut	Cut	(	Cut	Cut	Cut	C	cut	
Put this edge right against the bottom lip of where the case opens											
+	+		+	+		+	+		+	+	
+	$\langle + \rangle$	$\langle + \rangle$	$\langle + \rangle$	+	+	$\langle + \rangle$	$\langle + \rangle$	$\langle + \rangle$	( <del>+</del> )	$\langle + \rangle$	
+	+	( <del>+</del> )	( <del>+</del> )	+	+	( <del>+</del> )	+	+	+	+	
+	$\langle + \rangle$	+	+	+	+	+	+	( <del>+</del> )	( <del>+</del> )	(+)	

WiredWatts.com

WiredWatts.com

Cut Cut Cut Cut Cut Cut Holes are 1/2 inch, 5/8 inch, and 1 inch

WiredWatts.com

NOTE: DO NOT SCALE WHEN PRINTING Select "Actual Size" in the print options There are 6 large holes and 33 small, you may not need all of them